

FCW, LLC 5370 US HWY 77 Cortland, NE 68331 Phone: 402-798-8383 www.fcwguns.com www.marvelprecision.com Email: info@fcwguns.com



Dry Fire Device Instructions







Remove magazine and lock your conversion slide back and confirm the chamber is empty.

Take our dry fire device as shown in picture two and start it in the lower part of the slide. Simply push it flush against the breech insert. If needed push it up or down to center the head of the firing pin in the hole of the dry fire device as shown in picture three. It should be a snug fit so as to stay in place while you rack the slide. This will block the firing pin from being hit and also protect your hammer and our hardened breech face.

When ready to remove, simply slide a thin screwdriver under the top side and remove.

Thanks and enjoy.